



BUCKING CANNABIS HAS NEVER BEEN THIS EASY.

The MBX Bucker by Mobius is a reliable workhorse ergonomically designed to reduce operator fatigue and engineered for continuous operation. It can strip 150 lbs of flower per hour, and can buck both wet and dry material with the same machine. It's also the only commercial-scale buckler to offer integrated stem chipping to reduce waste volume, frequency of waste disposal, and Health Canada compliance for disposal with no further processing.

GENTLE ON FLOWER, TOUGH ON STEMS

Dieplates ranging from 4 to 7 feedholes accommodate stem sizes up to 1/2" diameter. Hole options include round and star-shaped configuration. The 1/2 HP variable speed motor is gentle on flower but offers uncompromising pulling power on stems. A stainless steel chute funnels bucked flower to a catch tote or optional conveyor for fully automated workflows.

INTEGRATED STEM CHIPPER

The Mobius MBX Bucker is the only commercially available cannabis and hemp buckler to include an integrated stem chipper. After the stem is pulled through the feedhole dieplate, it passes through 2 precision engineered stainless steel cutting blades powered by a 3/4 HP motor. Waste stems are consistently diced to a manageable size to more efficiently fill the catch tote, reduce how often the machine is emptied, and eliminate the need for further processing prior to disposal. For comparison, one bag of chipped stems is roughly equivalent to 20-25 bags of unchipped stems.

KEY FEATURES

- 150 lbs wet per hour bucking power offers 1250 lbs per shift
- Variable pulling speed for both wet and dry processing
- Quality stainless construction
- Integrated stem chipper simplifies waste disposal
- Indoor and outdoor wheel options accommodate all bucking scenarios
- GMP compliant and easy to clean
- Ergonomic, safety-first design for perpetual operation
- Replaces 5-7 hand buckers
- Roller rubber compound formulated to consistently grab stems without getting flat spots over time

SPECIFICATIONS

Wet / Dry Capable	Yes
Construction Inner Frame Rollers Hardware	304 Stainless Steel 6061 Aluminum - Clear Anodized Cast Polyurethane 18-8 Stainless Steel
Speed Adjustments	1 - 10
Number of Feed Holes	7
Max Hole Diameter	1/2"
Integrated Chipper	Yes
Stem Puller Motor	1/2 HP
Chipper Motor	3/4 HP
Number of Chipping Blades	2
Power Requirements	110V, 15AMPS
Disassembly Tools	5/32 Allen Key
Fits Through a 32" Door	Yes
Width	28"
Length	36"
Height	50"
Weight	275lbs
Warranty	1 year
Certifications	ESA Certification
Accessories	Various die plate configurations

Interested in adding an MBX Bucker to your trim room?
Contact us for a custom quote.